

Before you begin

Use this checklist with the product-specific instructions enclosed with your shade. Confirm inside or outside mount and a flat, suitable fixing surface. Check recess depth, handles and other obstructions. Plumridge will confirm the exact headrail clearance before ordering.

Check your size

These are 64-inch stock-drop shades with optional factory width trimming. The length is not cut down. On factory-cut inside-mount orders, submit your actual opening width unchanged: the factory takes the 1/4-inch total width deduction once.

Adhesive mounting

The shade includes double-sided installation tape and needs no mounting brackets. Follow the enclosed instructions for surface preparation, tape position, pressure and any waiting time before operation. Do not substitute the Cut-at-Home cutting instructions for this model.

Cordless operation

Move the bottom rail to adjust coverage, following the supplied operating instructions. Keep the rail level. If the shade binds or does not hold its position, stop and contact Plumridge.

Removal and paint

Adhesive removal may pull paint off the casing. In our installation experience, this happens often. Allow for possible touch-ups; careful removal does not guarantee that the paint will stay intact.

Need help?

Send Plumridge a photo of your shade, headrail, mounting surface and the instructions supplied in the box. We can help identify the correct fitting details before you begin.